

MANAGER MODE CODES

NOT DEPLOYED

MAX VAC:

Press "2" and then "ENTER"
Press "1" to turn MAX VAC ON
Press "0" to turn MAX VAC OFF
Press "ENTER" to save settings

CHIRP:

Press "3" and then "ENTER"
Press "1" to turn chirp ON
Press "0" to turn chirp OFF
Press "ENTER" to save settings

CALIBRATE THE DEVICE:

(Ensure suction cups are not touching anything)

Press "4" and then "ENTER"

VERIFY SERIAL NUMBER:

Press "5" and then "ENTER"

GSM:

Press "7" and then "ENTER"
Press "477" to turn GSM ON
Press "477" to turn GSM OFF
Press "ENTER" to save settings

BATTERY LIFE:

Press "8" and then "ENTER"

NEW ACTIVATION CODE:

PRESS "9" then "ENTER"

DEPLOYED

TOW MODE:

(deactivates alarm while in transit)

PRESS "8" then "6"
then "9" then "ENTER"

NEW ACTIVATION CODE:

PRESS "7" then "5"
then "3" then "ENTER"

**TO DEPLOY THE BARNACLE
TO THE VEHICLE AND
ACTIVATE THE PUMP:**

**Press "ENTER",
then "ENTER",
then "ENTER"**

FIRMWARE VERSION 2.15

**Some of these commands will
not work or be the same on
earlier versions of our firmware*

V1-8-11-18